



MINOR REPAIRS (repair kit)

Content:

- Marker:
Impregnated oil (neutral or colored)
- Marker:
Neutral satin finish oil
- Spatula
- Wood putty
- Sand paper

Steps to follow:

For surface scratches just apply impregnated oil and satin finish oil.

- 1- For deep scratches, apply wood putty with a spatula to the scratches trying not to overflow the cavities.
- 2- Sand lightly to even out the surface with a 120 grain sand paper.
- 3- Apply a thin coat of impregnated oil with the marker (neutral or coloured) and wipe off the excess with a cloth. It is recommended to use little amounts at a time until reaching the right shade. Allow 6 hours to dry.
- 4- Apply a thin coat of finishing oil with the marker the same way as you applied the impregnated oil. Allow a few hours drying time prior to light traffic.

* Note: Always perform repairs in the direction of the wood grain.